


# Datamate J-Tek Connectors

DATAMATE J-TEK

## Male Crimp Kit

- Part numbers are for a complete kit of a housing and the applicable number of contacts.
- Jackscrews are assembled where specified.
- Crimp contacts supplied loose.
- Crimp contacts are rear insertable and replaceable.
- Spare contacts are available.



WITHOUT JACKSCREWS	WITH JACKSCREWS														
<table border="1" style="background-color: #f4a460; width: 100%;"> <thead> <tr> <th colspan="2">CALCULATION</th> </tr> </thead> <tbody> <tr> <td><b>A</b></td> <td><math>B + 12</math></td> </tr> <tr> <td><b>B</b></td> <td>Total no. of contacts - 2</td> </tr> <tr> <td><b>C</b></td> <td><math>B + 7</math></td> </tr> </tbody> </table>		CALCULATION		<b>A</b>	$B + 12$	<b>B</b>	Total no. of contacts - 2	<b>C</b>	$B + 7$						
CALCULATION															
<b>A</b>	$B + 12$														
<b>B</b>	Total no. of contacts - 2														
<b>C</b>	$B + 7$														
TOOLS	WIRE STRIPPING DETAILS														
<p><b>Recommended Crimp Tool</b> - M22520/2-01</p> <p><b>Positioner</b> - Z80-193</p> <p><b>Contact Insertion/Removal Tool</b> - Z80-280</p> <ul style="list-style-type: none"> <li>Spare contacts shown on following pages.</li> <li>Instruction sheets available at <a href="http://www.harwin.com/instructions">www.harwin.com/instructions</a>.</li> </ul>															
HOW TO ORDER															
<p><b>M80 - 5XX XX 05</b></p>															
<table border="1" style="width: 100%;"> <thead> <tr> <th colspan="2">SERIES CODE</th> </tr> </thead> <tbody> <tr> <td><b>570</b></td> <td>Large Bore (22 AWG), without Jackscrews</td> </tr> <tr> <td><b>571</b></td> <td>Small Bore (24-28 AWG), without Jackscrews</td> </tr> <tr> <td><b>560</b></td> <td>Large Bore (22 AWG), with Jackscrews</td> </tr> <tr> <td><b>561</b></td> <td>Small Bore (24-28 AWG), with Jackscrews</td> </tr> </tbody> </table>	SERIES CODE		<b>570</b>	Large Bore (22 AWG), without Jackscrews	<b>571</b>	Small Bore (24-28 AWG), without Jackscrews	<b>560</b>	Large Bore (22 AWG), with Jackscrews	<b>561</b>	Small Bore (24-28 AWG), with Jackscrews	<table border="1" style="width: 100%;"> <thead> <tr> <th colspan="2">FINISH</th> </tr> </thead> <tbody> <tr> <td><b>05</b></td> <td>Gold</td> </tr> </tbody> </table>	FINISH		<b>05</b>	Gold
SERIES CODE															
<b>570</b>	Large Bore (22 AWG), without Jackscrews														
<b>571</b>	Small Bore (24-28 AWG), without Jackscrews														
<b>560</b>	Large Bore (22 AWG), with Jackscrews														
<b>561</b>	Small Bore (24-28 AWG), with Jackscrews														
FINISH															
<b>05</b>	Gold														
<table border="1" style="width: 100%;"> <thead> <tr> <th>TOTAL NO. OF CONTACTS</th> </tr> </thead> <tbody> <tr> <td><b>04, 06, 08, 10, 12, 14, 20, 26, 34, 42, 50</b></td> </tr> </tbody> </table>		TOTAL NO. OF CONTACTS	<b>04, 06, 08, 10, 12, 14, 20, 26, 34, 42, 50</b>												
TOTAL NO. OF CONTACTS															
<b>04, 06, 08, 10, 12, 14, 20, 26, 34, 42, 50</b>															

All dimensions in mm.