

Customer Information Sheet


IF IN DOUBT - ASK

©

NOT TO SCALE


THIRD ANGLE PROJECTION

ALL DIMENSIONS IN mm




ORDER CODE:
S01-806005KIT


CAN SHEET LENGTH:
 CAN SHEET WIDTH:
 CAN ETCHING PITCH:



VIEW OF FOLDED CAN FOR ILLUSTRATION ONLY




ETCHED CAN SHEET



RECOMMENDED PAD LAYOUT FOR S1711-46R


1/2 ETCHED LINES FOR FOLDING




RFI SHIELD CLIPS



NICKEL SILVER, HALF HARD NS106, TO BS1653 0.30mm THICK (UNPLATED)



SHIELD CAN KIT INSTRUCTION SHEET



- NOTES:
- S01-806005KIT IS COMPOSED OF:
 - 1 x Y0905-00: CLEAR HARWIN BOX,
 - 2 x S01-806005SHEET: ETCHED NICKEL SILVER CAN SHEETS,
 - 24 x S1711-46R: RFI SHIELD CLIPS IN STRIPS OF 12,
 - 1 x IS-39: SHIELD CAN KIT INSTRUCTION SHEET.
 - FOR COMPONENT DETAILS OF RFI SHIELD CLIP, SEE DRAWING S1711-46R.

| | | | |
|---------------|------|------------|-------|
| AB | 4 | 30.04.24 | 33993 |
| NAME | ISS. | DATE | CN/CO |
| APPROVED: | | A.BOXALL | |
| CHECKED: | | R.PORTLOCK | |
| DRAWN: | | S.BENNETT | |
| ASSEMBLY DRG: | | | |

HARWIN

www.harwin.com

TOLERANCES
 X. = ±1mm
 X.X = ±0.50mm
 X.XX = ±0.20mm
 X.XXX = ±0.01mm
 ANGLES = ±5°
 UNLESS STATED

THIS DRAWING AND ANY INFORMATION OR DESCRIPTIVE MATTER SET OUT HEREON ARE CONFIDENTIAL AND COPYRIGHT PROPERTY OF THE HARWIN GROUP AND MUST NOT BE DISCLOSED, LOANED, COPIED OR USED FOR MANUFACTURING, TENDERING OR FOR ANY OTHER PURPOSE WITHOUT THEIR WRITTEN PERMISSION.

MATERIAL:
 SEE ABOVE

TITLE:
EZ-BOARDWARE SHIELD CAN AND SMT RFI SHIELD CLIP KIT

DRAWING NUMBER:
S01-806005KIT

SHT
 2 OF 2

1



Your Kit contains:

- 2 x Shield Can Sheets
- 24 x RFI Shield Clips
- 1 x Instruction Sheet

Tools required:

- A pair of scissors
- A rule
- A solid, flat work surface


HARWIN

Shield Can Kit Instruction Sheet

S01-806005KIT


IS-39 Issue: 4 Date: 18/12/2023

2



Use this diagram as a guide when cutting your etched Shield Can Sheets.


3



Creating the blank:

- Cut along the etch lines to create blank size (Step 2).
- It's not necessary to cut all the way; fold the surplus section back and forth until it breaks away.


4



Creating the flat pattern:

- Remove corners of the sheet; one grid square equals 5mm can height.
- Cut one edge with scissors, then fold back and forth along the other edge until the square breaks away.
- Repeat on the remaining three corners.

5




Forming:

- Securely hold the rule along your fold line.
- Apply force to bend the sheet against the work surface.
- Ensure that the side is bent to 90° with etching inside the can.
- Repeat on the opposite side.

Note:

Maintaining your hold on the rule whilst bending will ensure that the edge has a sharper form.


6



Forming cont.:

- On the third side of the can, apply light force with hands to the fold line; forming a slight bend (above).
- Using your work surface, push the side flat against it (90° to top surface).
- Repeat on the opposite side.

7




You now have a finished can! Use the can with S1711-46R RFI Shield Clips provided.

Harwin recommend S1711-46R clips are reflow soldered to a PCB.

HARWIN

Pick & Place Ready By Design

- Simplifies production processes.
- Increased design flexibility and decreased costs.
- Surface mount designs available in tape & reel for fully automated assembly.
- Free samples available on-line at www.harwin.com
- Stocked in depth throughout our world-wide distribution network.



To check stock availability visit www.harwin.com

and enter part no. **S01-806005KIT**

